



ATTACHING THE STAINLESS STEEL BRACKET



Place stainless steel bracket
around lower part of the unit
to protect the activator.

Screw into stall wall as
shown using the two holes
on each side of the bracket.



IFEED[®]